

BURROW[®]RX

CARBON MONOXIDE SPRAYER

QUICK START GUIDE

- 1 **ADD ENGINE OIL.** Tip the carbon monoxide sprayer onto its back, remove the oil cap and use a funnel to put the provided motor oil into the engine. Put the oil cap back into position. Tip the CO sprayer back to an upright position.
- 2 Add gasoline into the tank. 91 octane or higher is recommended.
- 3 Fill smoke oil cup, located on the manifold, with Smoke Oil. Open valve to drop oil into manifold. Make sure to close valve.
- 4 Find an active burrow/tunnel to treat. If needed, use probe.
- 5 Set BurrowRx carbon monoxide sprayer near area to be treated and keep level or slightly tilted forward.
- 6 Place exhaust nozzle into burrow/tunnel.
- 7 Start engine.
- 8 Place soil over areas where smoke is escaping.
- 9 Run BurrowRx carbon monoxide sprayer for three minutes, and then shut off.
- 10 Repeat from step 3 if necessary. Due to different size tunnels/burrows, soil types and other conditions, several treatments may be needed.



For some tips and FAQs please check us out at BurrowRx.com